



Overview

This guide provides step-by-step instructions for properly securing the bare conductor to our Clamp Top HDPE insulators.

Materials Needed

- **Insulator** – Secured to crossarm
- **Bare Conductor**

Installation Steps

Setup:

Refer to our Line Post Installation Guide for detailed instructions on proper installation of the insulator onto the stud.

Step 1:

Position the clamp top so it is facing the proper orientation- ensure that the stationary part of the clamp is facing inside of any angle.

Step 2:

Place the conductor in the clamp saddle.

Step 3:

Tighten the hex bolt using your tool of choice.