



Overview

This guide provides step-by-step instructions for properly installing a Line Post HDPE insulator onto a cross arm.

Materials Needed

- **Line Post Insulator**
- **Installation hardware** – $\frac{3}{4}$ " stud and bolt for attachment (not provided)

Installation Steps

Step 1:

Screw in stud onto insulator base until it engages fully.

Step 2:

Place assembly on cross arm and ensure proper alignment based on conductor direction and tighten in bottom bolt.