



Overview

This guide provides step-by-step instructions for properly securing the conductor to our Trunion-top HDPE insulators.

Materials Needed

- **Insulator** - secured to crossarm
- **Bare Conductor**
- **Trunion Clamp** (not provided)

Installation Steps

Setup:

Refer to our Line Post Installation Guide for detailed instructions on proper installation of the insulator onto the stud.

Step 1:

Attach the trunion clamp to the trunion - this is not provided so use clamp of choice.

Step 2:

Position the trunion top so it is facing the proper orientation.

Step 3:

Place and secure the conductor into the appropriate trunion clamp.